


NOBÜ STARTED • Be sure to fully charge your toy before first use.


GETTING YOUR NEW

- \bullet Press and hold " $\mbox{\mbox{\boldmath U}}$ " on both the toy and the remote to turn ON.
- When the device is on, promptly press " $\dot{\mathbf{U}}$ " to switch to different vibration modes.
- \bullet Press and hold " $\mbox{\bf U}$ " on both the toy and the remote to turn OFF.



CHARGING YOUR NOBÜ

- When the vibrations become weak or stop but the LED light is still on, it is time to re-charge your toy,
- To begin charging your toy, attach the magnetic end of the charger to your toy's charging port, ensuring that the magnets line up with one another.
- Insert the other end of the recharging cord into any USB socket. The LED light will blink to indicate when the toy is recharging.
- After 2 hours, when the toy is fully charged, the LED light will remain on.





PLEASE NOTE

 Your nobü toy is not classified as a medical device. Do not use your toy around your chest or throat area. If you experience severe discomfort during use, stop using your nobü toy and consult your healthcare provider immediately.

SPECIFICATIONS

SIZE: 5½" X 15%"ø | 13.97cm X 4.12cmø

WEIGHT: 185g

MATERIALS: ABS + FDA-Approved Body-safe silicone

BATTERY: Li-ion 300mAh 37V

CHARGING TIME: 4 hours

USER TIME: Up to 1 hour depending on power setting

MAX NOISE LEVEL: <60dB

CLEANING, SAFETY AND STORAGE

- Wash the silicone section of your nobü toy with warm water and nobü antibacterial toy cleaner for best results. Never use cleaners that contain alcohol, petrol or acetone.
- Be sure to rinse your toy with hot water after cleaning and pat it dry with a lint-free cloth or towel.

 Standard and a clean day.

 The sure ways page 1 and 1 an
- Store your nobü in a clean, dry and dust-Pree place. Avoid leaving it in direct sunlight and NEVER expose it to extreme heat.



