


PINX

INSTRUCTION MANUAL

GETTING YOUR NEW NOBÜ STARTED

- Be sure to fully charge your toy before first use.
- Press and hold "U" to turn ON.
 When the device is on, promptly press "V" or "Λ" to switch to
- different vibration modes.

 Press " H " to enter climax mode.
- Press and hold ""
 "U" to turn OFF.
 Vibration Mode



CHARGING YOUR NOBÜ

- When the vibrations become weak or stop but the LED light is still on, it is time to re-charge your toy.
- To begin charging your toy, attach the magnetic contact points of the charging cable to the two metallic contact points found at the base of your toy (see illustration below).
- Insert the other end of the cable into any USB socket. The LED light will blink to indicate when the toy is recharging.
- After 3 hours, when the toy is fully charged, the LED light will remain on.



PLEASE NOTE

 Your nobü toy is not classified as a medical device. Do not use your toy around your chest or throat area. If you experience severe discomfort during use, stop using your nobü toy and consult your healthcare provider immediately.

SPECIFICATIONS

SIZE: 8" X 1½"ø | 20.32cm X 3.81cmø

WEIGHT: 152g

MATERIALS: FDA-Approved Body-safe silicone

BATTERY: Li-Ion 300mA 3.7V

CHARGING TIME: 3 hours at 5V 500mA

USER TIME: Up to 70 minutes depending on power setting

MAX NOISE LEVEL: <40dB

LICLEANING, SAFETY AND STORAGE

- Wash the silicone section of your nobü toy with warm water and nobü antibacterial toy cleaner for best results. Never use cleaners that contain alcohol, petrol or acetone.
- Be sure to rinse your toy with hot water after cleaning and pat it dry with a lint-free cloth or towel.

 Standard and a clean day.

 The sure ways page 1 and 1 an
- Store your nobü in a clean, dry and dust-free place. Avoid leaving it in direct sunlight and NEVER expose it to extreme heat.



