FLÖR

HANDHELD VIBE INSTRUCTION MANUAL



01

GETTING STARTED:

- Be sure to fully charge your toy before first use.
- Press and hold \Diamond to turn the device on.
- When the device is on, promptly press \lozenge again to filter through various vibration functions.
- Press and hold \Diamond to turn the device off.
- Make sure that the LED light is off before storing.

02

CHARGING YOUR NOBÜ:

- When the motor becomes weak or stops, it is time to charge your toy.
- Place your toy on top of the circular charging base, ensuring that the magnets line up with each other.
- Insert the USB end of the charger into any USB dock or socket. The LED light will blink to indicate that the toy is charging.
- After about 2 hours, the LED light will stop blinking and remain on to indicate that the toy is fully charged.

CLEANING

AND STORAGE:

- Always wash your toy with warm water and soap after use. For best results, we recommend using Nobü antibacterial toy cleaner. Do not use cleaners that contain alcohol, petrol or acetone.
- Rinse your toy with hot water after cleaning and pat dry with a lint-free towel or cloth.
- Store your toy in a clean, dry and dust-free place. Avoid leaving it in direct sunlight, and never expose your toy to extreme heat.



PRODUCT SPECIFICATIONS:

SIZE: 3½ x 2" Ø (8.25cm x 5.08cm Ø)

WEIGHT: 101 grams

MATERIALS: Medical grade silicone + ABS.

WATERPROOF LEVEL: IPX6

(splashproof).

NOISE LEVEL: <60dB


INTERNAL BATTERY: Lithium 250 mAh USER TIME: Up to 1½ hours depending on

power setting.

CHARGING TIME: 2 hours

FOR YOUR SAFETY: Not classified as a medical device. Do not use your toy around your neck, chest or throat area. If you experience severe discomfort during use, stop use immediately and consult your healthcare provider. Sold as an adult novelty only. Not intended to treat, cure, or prevent disease. Keep away from children.

o nobu_toys





VISIT US ONLINE TO BROWSE OUR COMPLETE COLLECTION