# SONO

#### INTIMATE DUAL VIBE

INSTRUCTION MANUAL



## **GETTING** STARTED:

- Be sure to fully charge your toy before first use.
- Press and hold  $\upsilon$  to turn the device on.
- Promptly press **(**) again to filter through various vibration modes.
- When the device is on, press 


  to increase speed and ▼ to decrease speed.
- Press and hold  $\circlearrowleft$  to turn the device off
- Make sure that the LFD light is off before storing.

#### **CHARGING** YOUR NOBÜ:


- When the motor becomes weak or stops, it is time to charge your toy.
- Insert the DC plug into your toys DC charging port (see illustration below).
- Insert the USB end of the charger into any USB dock or socket. The LED light will blink to indicate that the toy is charging.
- After about 2.5 hours, the LED light will stop blinking and remain on to indicate that the toy is fully charged.

# **CLEANING** AND STORAGE:

- Always wash your toy with warm water and soap after use. For best results, we recommend using Nobü antibacterial toy cleaner. Do not use cleaners that contain alcohol, petrol or acetone.
- Rinse your toy with hot water after cleaning and pat dry with a lint-free towel or cloth.
- Store your toy in a clean, dry and dust-free place. Avoid leaving it in direct sunlight, and never expose your toy to extreme heat.



PRODUCT ID: NB001557 UPC: 694182020705



## **PRODUCT SPECIFICATIONS:**

**SIZE:** 8" x 1¼" Ø (20.32 cm x 3.17 cm Ø)

**WEIGHT:** 167 grams

**MATERIALS:** Medical grade silicone + ABS.

WATERPROOF LEVEL: IPX6

(splashproof).

NOISE LEVEL: <40dB

INTERNAL BATTERY: Li-polymer. **USER TIME:** Up to 1 hour depending on

power setting.

**CHARGING TIME: 2.5 hours** 

nobu\_toys



f nobutoyscanada



TO BROWSE