RORI

RABBIT DUAL VIBE INSTRUCTION MANUAL

GETTING STARTED:


- Be sure to fully charge your toy before first use.
- Press and hold \circlearrowleft to turn the device on.
- Promptly press ∼ to filter through various shaft vibration modes.
- Promptly press ≈ to filter through various rabbit stimulator functions.
- Promptly press + to increase vibration intensity, and — to decrease intensity.
- Press and hold \circlearrowleft to turn the device off.
- Make sure that the LED light is off before storing.

CHARGING YOUR NOBÜ:


- When the motor becomes weak or stops, it is time to charge your toy.
- Insert the DC plug into your toys DC charging port (see illustration below).
- Insert the USB end of the charger into any USB dock or socket. The LED light will blink to indicate that the toy is charging.
- After about 3 hours, the LED light will stop blinking and remain on to indicate that the toy is fully charged.

CLEANING AND STORAGE:

- Always wash your toy with warm water and soap after use. For best results, we recommend using Nobü antibacterial toy cleaner. Do not use cleaners that contain alcohol, petrol or acetone.
- Rinse your toy with hot water after cleaning and pat dry with a lint-free towel or cloth.
- Store your toy in a clean, dry and dust-free place. Avoid leaving it in direct sunlight, and never expose your toy to extreme heat.



PRODUCT ID: NB001859 UPC: 694182023911



PRODUCT SPECIFICATIONS:

SIZE: 8½" x 1¼" Ø (21.59cm x 3.17cm Ø)

WEIGHT: 200 grams

MATERIALS: Medical grade silicone + ABS. WATERPROOF LEVEL: IPX7 (submersible

up to 1 meter for 30 minutes). NOISE LEVEL: <60dB

INTERNAL BATTERY: Li-ion Battery **USER TIME:** Up to 2 hours depending on

power setting.

CHARGING TIME: 3 hours



nobutoyscanada



TO BROWSE